

JUPIO Pentax D-Li106



Batterie JUPIO compatible:

Pentax D-Li106

Panasonic CGA-S005E | DMW-BCC12

Ricoh DB-60

Leica BP-DC4

Capacité: 1100 mAh

Garantie 3 ans

Référence :CPA0002

Code barre :8717825941099

Compatible pour :

- Leica

D-Lux 2 / D-Lux 3

- Panasonic

HMX-R10BP, HMX-R10, GX200, G700SE, G700, G600, GR Digital IV, GR Digital III, Caplio R5, Caplio R40, Caplio R4, Caplio R30, Caplio R3, Caplio GX200, Caplio GX100, Caplio G600, Caplio GR Digital III, Caplio GR Digital II, Caplio GR Digital, X90, Optio X90, D-LUX3, D-LUX2, D-LUX 4, D-LUX 3, D-LUX 2, C-LUX1, FinePix F47fd, FinePix F45fd, FinePix F40fd, Finepix F20, Lumix DMC-LX3S, Lumix DMC-LX3K, Lumix DMC-LX3GK, Lumix DMC-LX3EF-K, Lumix DMC-LX3, Lumix DMC-LX2S, Lumix DMC-LX2K, Lumix DMC-LX2EG-S, Lumix DMC-LX2EGM, Lumix DMC-LX2EG-K, Lumix DMC-LX2EG, Lumix DMC-LX2EF-S, Lumix DMC-LX2EF, Lumix DMC-LX2, Lumix DMC-LX1S-B, Lumix DMC-LX1-S, Lumix DMC-LX1K-B, Lumix DMC-LX1-K, Lumix DMC-LX1GN, Lumix DMC-LX1GK, Lumix DMC-LX1EG-S, Lumix DMC-LX1EG-K, Lumix DMC-LX1BS, Lumix DMC-LX1, Lumix DMC-FX9-S, Lumix DMC-FX9-R, Lumix DMC-FX9-K, Lumix DMC-FX9-H, Lumix DMC-FX9GN, Lumix DMC-FX9GK, Lumix DMC-FX9EG-S, Lumix DMC-FX9EG-R, Lumix DMC-FX9EG-K, Lumix DMC-FX9EG, Lumix DMC-FX9EF-S, Lumix DMC-FX9EF-K, Lumix DMC-FX9EB-S, Lumix DMC-FX9EBS, Lumix DMC-FX9EB-K, Lumix DMC-FX9BS, Lumix DMC-FX9BB, Lumix DMC-FX9, Lumix DMC-FX8-S, Lumix DMC-FX8-P, Lumix DMC-FX8-K, Lumix DMC-FX8GN, Lumix DMC-FX8GK, Lumix DMC-FX8EG-S, Lumix DMC-FX8EG-P, Lumix DMC-FX8EG-K, Lumix DMC-FX8EG-A, Lumix DMC-FX8EBB, Lumix DMC-FX8BS, Lumix DMC-FX8-A, Lumix DMC-FX8, Lumix DMC-FX50K, Lumix DMC-FX50EGM, Lumix DMC-FX50EG, Lumix DMC-FX50EF, Lumix DMC-FX50, Lumix DMC-FX3S, Lumix DMC-FX3K, Lumix DMC-FX3EG-S, Lumix DMC-FX3EGM, Lumix DMC-FX3EG, Lumix DMC-FX3EF-S, Lumix DMC-FX3EF, Lumix DMC-FX3, Lumix DMC-FX180S, Lumix DMC-FX180N, Lumix DMC-FX180K, Lumix DMC-FX180GK, Lumix DMC-FX180, Lumix DMC-FX150S, Lumix DMC-FX150K, Lumix DMC-FX150EFK, Lumix DMC-FX150, Lumix DMC-FX12S, Lumix DMC-FX12K, Lumix DMC-FX12GK, Lumix DMC-FX12EG-S, Lumix DMC-FX12EG-K, Lumix DMC-FX12EG, Lumix DMC-FX12EF-S, Lumix DMC-FX12EB-S, Lumix DMC-FX12EB-K, Lumix DMC-FX12, Lumix DMC-FX10S, Lumix DMC-FX10P, Lumix DMC-FX10EG-S, Lumix DMC-FX10EG-A, Lumix DMC-FX10EG, Lumix DMC-FX10EF-S, Lumix DMC-FX10EB-S, Lumix DMC-FX10EB-K, Lumix DMC-FX10A, Lumix DMC-FX100GK, Lumix DMC-FX100EG-S, Lumix

DMC-FX100EG-K, Lumix DMC-FX100EG, Lumix DMC-FX100EF-S, Lumix DMC-FX100EF-N, Lumix DMC-FX100EF-K, Lumix DMC-FX10, Lumix DMC-FX07K, Lumix DMC-FX07EGM, Lumix DMC-FX07EG, Lumix DMC-FX07EF-S, Lumix DMC-FX07EF, Lumix DMC-FX07, Lumix DMC-FX01-W, Lumix DMC-FX01-S, Lumix DMC-FX01-P, Lumix DMC-FX01-K, Lumix DMC-FX01GK, Lumix DMC-FX01EG-S, Lumix DMC-FX01EG-K, Lumix DMC-FX01EG-A, Lumix DMC-FX01EG, Lumix DMC-FX01EF-W, Lumix DMC-FX01EF-S, Lumix DMC-FX01EF-K, Lumix DMC-FX01EF-A, Lumix DMC-FX01EB-W, Lumix DMC-FX01EB-S, Lumix DMC-FX01EB-K, Lumix DMC-FX01BS, Lumix DMC-FX01BB, Lumix DMC-FX01-A, Lumix DMC-FX01, Lumix DMC-FS2, Lumix DMC-FS1

- Ricoh

Caplio R3 / R4 / R5 / R30 / R40 / GR / GR Digital II / GR Digital III / GX 100 / GX 200 / G600 / G700 / G700SE